



Techno Metal Post of Albany
 102 Willsie Road
 East Berne, NY 12059

Telephone: (518) 872-0511
 Mobile: (518) 378-0140
 Fax: (518) 872-0511

info@technometalpostny.com

TECHNO METAL POST vs. CONCRETE

TASK	TECHNO METAL POST	CONCRETE
Contractor Materials Required	None	Bigfoot System® Sonotubes® Concrete Rebar
Contractor Tools	Tape Measure Marking Paint Stakes (optional)	Shovels/Excavator Level Screwdriver/Drill Tape Measure Knife
Labor	Mark Post Location	Excavate Holes Cut Rings/Set Bigfoot® Cut Sonotubes® to Length Align Tubes Backfill Holes Pour Concrete
Construction Time	Install (6) Posts 2 hours No Inspection Required	Excavate and Prep 1-2 days Building Inspection 1-2 days Pour Concrete ½-1 day Cure Concrete ½-1 day
Total Number of Days	Install Posts ½-1 day	Install Posts 3-5 days